

# SELECTION GUIDE - ARCHITECTURAL



| SUBSTRATE TYPE              | PANEL TYPE  |   |   |   |   |                      |                |     |
|-----------------------------|---|---|---|---|---|----------------------|----------------|-----|
|                             | Plywood   | MDF   | Particle board  | Acoustic panel                                  | Honeycomb                                       | Fibrous cement board | Exterior panel |     |
| Steel frames<br>e.g. Rhondo | PC-SF1 + PC-M1B<br>PC-SF1 + PC-M2H<br>PC-SF1 + PC-SM2<br>PC-SF1 + PC-SM2H | PC-SF1 + PC-M1B<br>PC-SF1 + PC-SM2H                                       | PC-SF1 + PC-M1B<br>PC-SF1 + PC-SM2H<br>+ glue thread                      |   | PC-SF1 + PC-SM2                                 | PC-SF1 + PC-SM2      | N/A            | N/A |
| Timber battens<br>or frames | PC-F1A + PC-VM1<br>PC-F1A + PC-M2H<br>PC-F1A + PC-SM2H                    | PC-F1A + PC-VM1<br>PC-F1A + PC-M2H  | PC-F1A + PC-VM1<br>PC-F1A + PC-M2H  |   | LP-F8 + LP-SM8AS                                | LP-F8 + LP-SM8AS     | N/A            | N/A |
| Concrete +<br>timber batten | PC-F1A + PC-M2H<br>PC-F1A + PC-SM2<br>PC-F1A + PC-SM2H                    | PC-F1A + PC-M2H<br>PC-F1A + PC-SM2<br>PC-F1A + PC-SM2H                    | PC-F1A + PC-M2H<br>PC-F1A + PC-SM2<br>PC-F1A + PC-SM2H                    | Must use<br>Timber batten<br>+ LP-F8 + LP-SM8AS | Must use<br>Timber batten<br>+ LP-F8 + LP-SM8AS | N/A                  | N/A            |     |
| Drywall<br>e.g. Gib Board   | LP-DF8 + LP-M8A<br>LP-DF8 + LP-SM8AS                                      | LP-DF8 + LP-M8A<br>LP-DF8 + LP-SM8AS                                      | LP-DF8 + LP-M8A<br>LP-DF8 + LP-SM8AS                                      | LP-DF8 + LP-SM8AS<br>with HMA (hot glue)        | LP-DF8 + LP-SM8AS<br>with epoxy glue            | N/A                  | N/A            |     |
| Plywood, MDF                | PC-F1A + PC-M1B<br>PC-F1A + PC-M2H<br>PC-F1A + PC-SM2<br>PC-F1A + PC-SM2H | PC-F1A + PC-M1B<br>PC-F1A + PC-M2H<br>PC-F1A + PC-SM2<br>PC-F1A + PC-SM2H | PC-F1A + PC-M1B<br>PC-F1A + PC-M2H<br>PC-F1A + PC-SM2<br>PC-F1A + PC-SM2H | LP-F8 + LP-SM8AS                                | LP-F8 + LP-SM8AS<br>with epoxy glue             |                      |                |     |

This Clip Selection Guide should be used as a general guide only. Please email [technical@fastmount.com](mailto:technical@fastmount.com) for more detailed advice if required. For overhead panels Fastmount strongly recommends a trial sample be made to prove compatibility of our systems with the panels and substrates in your project.